




Make a Call with a Headset

1. Plug in a headset.
2. Enter a number using the keypad.
3. Press **Headset** .

Make a Call with the Speakerphone

1. Enter a number using the keypad.
2. Press **Speakerphone** .

Mute Your Audio


1. Press **Mute**  soft key.
2. Press **Mute** again to turn mute off.

Listen to Your Voice Messages

The Message Waiting Indicator on the idle screen indicates that you have new voice messages waiting.

The power indicator LED slow flashes red.

To listen to voice mail messages:

1. Press  or the **Connect** soft key.
2. Follow the voice prompts to listen to your voice messages and enter your pin.

Do Not Disturb mode

To access **DO NOT DISTURB** press the **DND** key.



Adjust the Volume in a Call

Press **Volume**  left or right to adjust the handset, headset, or speakerphone volume, during a call.

Adjust the Ringtone Volume

Press **Volume**  left or right to adjust the ringer volume when the phone is not in use.

Change the Ringtone

1. Press the Menu soft key when the phone is idle, and then select **Basic** → **Sound** → **Ring Tones**
2. Press  or  to select the desired ring tone.
3. Press the Save soft key to accept the change.

Notes