





Your Phone



- ① Handset
- ② Base Station
- ③ Charger Cradle
- ④ Call history
- ⑤ Line Status
- ⑥ Place internal call
- ⑦ Directory
- ⑧ Decrease ringer volume
- ⑨ Increase ringer volume

Basic Operations



Turning Handset On/Off:

- Press , then the LCD screen lights up.
- Place the Handset in the charger cradle to turn on automatically.
- Long press  again to turn the Handset off.

Locking/Unlocking keypad:

- Long press  when the Handset is idle to lock the keypad.
- Long press  again to unlock the keypad.

Switching Silent Mode On/Off:

- Long press  when the Handset is idle to lock the keypad.
- Long press  again to unlock the keypad.



Access the Directory

- Press the **OK** key to enter the main menu, and then select **Directory**.



To add a contact

1. Press the **OK** key to enter the main menu, and then select **Directory**.
2. Press the **Options** soft key, and then select **New Contact**.
3. Enter the desired values in the **Name**, **Number** and **Mobile** fields.
4. Press the **Save** soft key to accept the change.


To edit a contact

1. Press the **OK** key to enter the main menu, and then select **Directory**.
2. Press  or  to highlight the desired entry.
3. Press the **Options** soft key, and then select **Edit**.
4. Edit the values in the **Name**, **Number** and **Mobile** fields.
5. Press the **Save** soft key to accept the change.








To delete a contact

1. Press the **OK** key to enter the main menu, and then select **Directory**.
2. Press  or  to highlight the desired entry.
3. Press the **Options** soft key, and then select **Delete** to delete the selected entry.

Make a Call

Enter the desired number when the handset is idle, and then press .

To place a call from the local directory

1. Press  when the handset is idle.
2. Press  or  to highlight the desired entry, and then press  .
If both the office number and mobile number are stored, press  or  to highlight the desired number, and then press  again.

Answer a Call

Press the **Accept** soft key.


Put a Call on Hold

1. Press the **Options** soft key during a call, and then select **Hold**.
2. If there is only a call on hold, press the **Resume** soft key.

Transfer a Call to Another Person

1. Press the **Options** soft key during call, and then select **Transfer**.
2. Enter the number you want to transfers the call to.
3. Press **Transfer** soft key.

Make a Call with the Speakerphone

1. Enter a number using the keypad.
2. Press **Speakerphone**  .

Mute Your Audio

1. Press **Mute** key.
2. Press **Mute** again to turn mute off.



Listen to Your Voice Messages

Press **Messages** keys and follow the voice prompts. To check messages for a specific line, press the line button first.

Adjust the Volume in a Call


Whilst in call, press  or  .


Adjust the Ringtone Volume

Press  or  , whilst

Handset Registration

The handset in the W52P package is pre-registered to the base station. Internal handset number and name display on the idle screen after turning the handset on. If your handset is not pre-registered to the base station, do one of the followings to register it manually:

- If the handset LCD screen prompts “Searching for Base”, long press  on the base station till the registration LED flashes. Then press the **OK** key to enter the main menu, and then select **Settings** → **Registration** → **Register Handset** to register the handset.

- If the handset LCD screen prompts “Press base page 2s then press OK”, long press  on the base station till the registration LED flashes. Then press the **OK** soft key on the handset.

Notes

